

BALANCE keyboard

User Guide



contour 

Box Contents

1. Balance Keyboard
2. Wireless Receiver
3. Two AAA Batteries

2

3



1





Step 1:
Remove the back housing and
insert AAA batteries.

Remove Wireless Receiver from
housing.



Step 2:
Plug the Wireless Receiver into an
open USB port.



Step 3:
Enjoy using your Balance Keyboard!

Function and Media Control Keys

- A. Media Control
- B. Application Functions
- C. Interface Functions
- D. Volume Control
- E. Fn Key



For additional mouse features and specific Mac settings, please download our driver at www.contour-design.co.uk.

Function and Media Control Keys

Media Control



Back Stop Play/Pause Forward

Application Functions



Calculator Web Mail Settings

Interface Functions



Volume Control



Mute Volume Down Volume Up



Fn Key (Activate F1-F12 functions)

Hold Fn Key with desired function or quickly release Fn Key to activate Fn lock.

Connection Troubleshooting

In the event that your Balance Keyboard loses connection, please try the following solutions:

- Make sure the wireless receiver is plugged into a working USB port on your computer. Unplug the receiver and re-insert it after a few seconds
- Verify that the batteries in the keyboard are fully charged. Remove one battery and re-insert it after a couple of seconds.
- Confirm that the wireless receiver is not too far from the keyboard, or too close to other wireless devices.
- Press the Reset button under the keyboard while the button itself is very close to the wireless receiver.

If trouble persists please consult our online troubleshooting guide at www.contour-design.co.uk.

For more information please visit:
www.contour-design.co.uk

Kingsbury House
468 Church Lane
London, NW9 8UA
United Kingdom
Phone: +45 70 27 02 27
Email: info@contour-design.com

Tested to comply with FCC
and IC standards.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications.

Le présent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

Warranty

If there is a functional defect due to faulty manufacturing, we will replace the product. This warranty does not cover damage that results from misuse of the product.

Attention!

If you attempt to dismantle your RollerMouse, you will invalidate your warranty.

contour 